




DVD1195
User Manual



Please read this User Manual carefully to ensure proper
Use of this product and keep this manual for future
reference

Content

Introduction

■ Safety Precautions	2
■ Important Safety Instructions	3
■ Caution	5
■ Features	6
■ Front Panel and Rear Panel Illustration	7
■ Remote Control	8

Connections


■ Connecting to a TV set	9
■ Connecting to an AV Receiver with 5.1 Channel Analog Audio Input	10
■ Connecting to an AV Receiver with Digital Audio Input	11

Advanced Features

■ The Setup Menu System	12
■ Remote Control Operation	28
■ MPEG4/MP3 Playback	32
■ USB interface	33
■ Kodak Picture CD Playback	34

Others

■ Troubleshooting	35
■ Remote Control Preparation	36
■ Specifications	37



THE LIGHTNING FLASH WITH ARROWHEAD SYMBOL WITHIN AN EQUILATERAL TRIANGLE IS INTENDED TO ALERT THE USER TO THE PRESENCE OF UNINSULATED "DANGEROUS VOLTAGE" WITHIN THE UNIT'S CABINET THAT MAY BE OF SUFFICIENT MAGNITUDE TO CONSTITUTE A RISK OF ELECTRIC SHOCK TO PERSONS.



THE EXCLAMATION POINT WITHIN AN EQUILATERAL TRIANGLE IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE MANUAL ACCOMPANYING THE UNIT.

WARNING:

TO PREVENT FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THE UNIT TO RAIN OR MOISTURE. NEVER ATTEMPT TO OPEN THE CABINET. DANGEROUS HIGH VOLTAGES ARE PRESENTED IN THE UNIT. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

CAUTION:

TO PREVENT ELECTRIC SHOCK, MATCH WIDE-BLADE PLUG WITH WIDE SLOT AND FULLY INSERT.
THE APPARATUS SHALL NOT BE EXPOSED TO WATER AND NO OBJECTS FILLED WITH LIQUID SUCH AS VASES SHALL BE PLACED ON THE APPARATUS.

CAUTION:

THE UNIT EMPLOYS A LASER SYSTEM. TO ENSURE THE PROPER USE OF THE UNIT, READ THIS MANUAL CAREFULLY AND KEEP IT FOR FUTURE REFERENCE.

IF THE UNIT REQUIRES SERVICING, CONTACT THE SELLER OR SEE "TROUBLESHOOTING".

TO PREVENT DIRECT EXPOSURE TO THE LASER RADIATION, DO NOT OPEN THE CABINET. VISIBLE LASER MAY RADIATE WHEN THE CABINET IS OPENED OR THE INTERLOCKS ARE DEFEATED. DO NOT STARE INTO THE LASER BEAMS.

CAUTION:

THE DVD VIDEO PLAYER IS A CLASS 1 LASER PRODUCT. USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

AS THE LASER BEAM USED IN THIS DVD VIDEO PLAYER IS HARMFUL TO THE EYES, DO NOT ATTEMPT TO DISASSEMBLE THE CABINET.

REFER SERVICING TO QUALIFIED PERSONNEL ONLY.

WARNING:

FCC REGULATIONS STATE THAT ANY CHANGE OR MODIFICATION TO THE EQUIPMENT, NOT EXPRESSLY APPROVED BY MAKER OR ITS AUTHORIZED PARTIES, COULD VOID USER'S AUTHORITY TO OPERATE THIS EQUIPMENT.

Important Safety Instructions

Introduction

1. Read Instructions

All the safety and operating instructions should be read before the product is operated.

2. Retain Instructions

The safety and operating instructions should be retained for future reference.

3. Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

4. Follow Instructions

All operating instructions should be followed.

5. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6. Attachments

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

7. Water and Moisture

Do not use this product near water for example, near a bathtub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

8. Accessories

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

9. Portable Cart Warning

A product and cart combination should be moved with care. Quick stop, excessive force, and uneven surface may cause the product and cart combination to overturn.

10. Ventilation

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

11. Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power or other sources, refer to the operating instructions.

12. Grounding or Polarization

This product may be equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

13. Power Cord Protection

Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.




(Symbol provided by RETAC)

Important Safety Instructions

Introduction

14. Outdoor Antenna Grounding

If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See figure below.



15. Lightning

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power line surges.

16. Power Lines

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

17. Overloading

Do not overload wall outlets, extension cords, or integral convenience receptacles, as this can result in a risk of fire or electric shock.

18. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

19. Servicing

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

20. Damage Requiring Service

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- A) When the power-supply cord or plug is damaged,
- B) If liquid has been spilled, or objects have fallen into the product,
- C) If the product has been exposed to rain or water,
- D) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation,
- E) If the product has been dropped or damaged in any way,
- F) When the product exhibits a distinct change in performance this indicates a need for service.

21. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

22. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

23. Wall or Ceiling Mounting

The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

24. Heat

The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

- Please use the original box and packing materials for safe transportation of this product.

- It is normal for the cover and rear panel to become warm after the player has been operating for an extended period of time.

- Do not move this product during playback. Doing so may cause damage to the pickup and the disc.

Press **OPEN/CLOSE** on the front panel or remote to open or close the disc tray. Do not push or touch the tray while it is opening or closing.

Features

Introduction

- Full compatibility with MPEG4 , DVD,CD,MP3,Kodak Picture CD,CD-R and CD-RW(finalized)
- Screensaver
- Multiple playback modes:program,search
-
- S-video,composite cideo and component(Y,Pb,P r)video outputs

Disc formats supported by this player:



MPEG4 files on discs



Multi-angle



Dolby Digital



Subtitle choices




KODAK picture CD



Audio choices



Mp3 files on CD-R/CD-RW



TV Aspect Ratio



DVD video



Parental lock

This product incorporates copyright protection technology that is protected by method claims of certain U.S.patents and other intellectual property rights owned by Macrovision Corporation and other rights


The product complies with the KODAK Picture CD format and will display KODAK Picture CDs. The "KODAK Picture CD Compatible" logo is a trademark of Eastman Kodak Company and is used with permission.

Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. © 1992-1997 Dolby Laboratories, Inc. All rights reserved.

Front Panel and Rear Panel Illustration


Introduction

Front panel



- | | | |
|--------------|---------------------|---------------------|
| ① POWER | ⑤ PLAY/PAUSE BUTTON | ⑧ NEXT BUTTON |
| ② LED SCREEN | ⑥ R/L BUTTON | ⑨ OPEN/CLOSE BUTTON |
| ③ SENSOR | ⑦ FREV BUTTON | ⑩ USB |
| ④ CABIN DOOR | | |

Rear panel




- | | | |
|---|-------------------------------------|---|
| ① 5.1CH Audio output
(FL, FR, SL, SR, CEN, SW) | ② Stereo Audio OUT | ③ Digital Audio COAXIAL output jack |
| ④ S-VIDEO output jack | ⑤ Digital Audio Optical output jack | ⑥ VGA OUT |
| ⑦ GAME | ⑧ MIC | ⑨ Component Video output
(Y, Pb, Pr) |
| ⑩ COMPOSITE VIDEO output jack | | |

Remote Control

Introduction

Remote Control




Note:

1. Please note that reference numbers for the remote are described beginning on page 18 of this manual.
2. In this manual, "◀" "▶" "↶" "↷" "↵" "↶" "↷" will be used to represent different NAVIGATION ARROWS on the remote respectively.
3. In order to operate any of the remote functions, you must first press the Power button on the DVD player.

Connecting to a TV Set


Connections



Notes:

There are three ways of connecting the player's AV output to the TV set:

1. S-video cable and left/right audio cable [set the (Video Type) to (S-Video)].
2. Composite video cable and left/right audio cable.
3. Component video cable and left/right audio cable [set the (Video Type) to (Y, Pb, Pr)].




Notes:

1. Set the TV to the AV input connected to the DVD player.
2. Set the Amplifier to the AV input connected to the DVD player.

Connecting to an AV Amplifier with Digital Audio Input

Connections



Notes:


1. Select the Coaxial digital audio output.
2. Set the player's Audio out to **Raw** or **PCM** mode .
3. Set the digital Amplifier to the AV input connected to the DVD player.

The Setup Menu System


Advanced Features

1. General Steps of setup menu

A) Press the setup button, the main setup menu appears.



B) Press the Left and Right arrow buttons to highlight the icon of the desired page, then press the Down or Right arrow button to activate that page; For example, if you want to setup the video page, press Right to highlight the video icon, the video page will be displayed on the screen.



C) Press the Down arrow button to highlight the desired option. Press Enter or press Right to select. The choices of that option appear on the right; For example, press the Down arrow button to highlight the BRIGHTNESS option, the press Enter to select, the brightness choices appear on the right.



A) Press the Arrow buttons to highlight the Exit Setup option, then press Enter or Setup again to exit Setup Menu.


2. Setup Items Introduction

2.1 SYSTEM SETUP

The system setup options are illustrated below:

2.1.1 SOURCE

There are 3 kinds of sources illustrated below.




The Setup Menu System

Advanced Features

2.1.2 TV SYSTEM

According to the Color System of the TV, you can choose the TV System.




2.1.3 VIDEO

According to the output jack of TV set, you can choose S-VIDEO, YUV, P-SCAN, Y, Pb, Pr.

Notes:

Only choose PSCAN if your DVD player is connected to a Progressive scan TV with Y, Cb, Cr cables.




The Setup Menu System

Advanced Features


2.1.4 TVTYPE

According to the TV type, you can choose 16:9, 4:3LB or 4:3PS.



2.1.5 PASSWORD

The password option is initialized locked, and you can not set the ratings limit or change the password. In order for the Ratings feature to work, the password mode must be turned on. If you want to set the ratings limit, you will need to enter the default password. Which is 6666, then press Enter to confirm. To change the password, you will be prompted for the old password, then be prompted for a new. Enter a 4-digit number (this is your password). Press remember your PASSWORD, as the DEFAULT setting will revert everything. But the PASSWORD to the factory defaults.




The Setup Menu System

Advanced Features


2.1.6 RATING

The Rating feature is a rating limit system, like movie ratings. It works with DVD discs that have been assigned a rating. This helps you control the types for DVDs that your family watches.



2.1.7 DEFAULT

The DEFAULT setup options are RESTORE factory setup. Let your player work on best state.



When your unit does not work properly, it may probably result from some wrong settings. Please try the Restore Factory Setting function to see if the unit can restore to its normal working status.

The Setup Menu System

Advanced Features

2.2 LANGUAGE SETUP

The language setup options are illustrated below:

2.2.1 OSD LANGUAGE

Highlight the OSD LANGUAGE option, and press the Arrow buttons to choose the OSD language you prefer. Press Enter to confirm, And it will display OSD in that language.



2.2.2 AUDIOLANG

Highlight the AUDIO LANG option, and press the Arrow buttons to choose the audio language you prefer. Press Enter to confirm. If the disc you are playing has that language available, it will output that language.



2.2.3 SUBTITLE LANG

Highlight the SUBTITLE LANG option, and press the Arrow buttons to choose the subtitle language you prefer. Press Enter to confirm. If the disc you are playing has that language available, it will display subtitles in that language.



The Setup Menu System

Advanced Features

2.2.4 MENU LANG

Highlight the MENU LANG option, and press the Arrow buttons to choose the menu language you prefer. Press Enter to confirm. If you disc you are playing has that language, Availabel. It will display the menu in the language..

Notes:

If your preferred language is not available, the disc s default language will be played.



2.2.5 DIVX[R] VOD

Video on Demand Register Code, which for download Divx video from Internet.



2.2.6 Subtitle Direction

To display Subtitle from left to right or right to left.



2.3 AUDIO SETUP

The audio setup options are illustrated below:


2.3.1 AUDIO OUT

Highlight the **AUDIO OUT** option, and press the Arrow buttons to choose the audio output mode you prefer. Press Enter to confirm; There are 3 optional audio output modes: SPDIF/OFF, SPDIF / RAW, and SPDIF/ PCM.



2.3.2 KEY

Use the Up and Down arrow button to move the scroll and adjust the key.




The Setup Menu System

Advanced Features

2.4 VIDEO SETUP

The video setup options are illustrated below:



2.4.1 BRIGHTNESS

Use the Up and Down arrow buttons to move the scroll and adjust the brightness.




The Setup Menu System

Advanced Features


2.4.2 CONTRAST

Use the Up and Down arrow buttons to move the scroll and adjust the contrast.




2.4.3 HUE

Use the Up and Down arrow buttons to move the scroll and adjust the HUE



2.4.4 SATURATION

Use the Up and Down arrow buttons to move the scroll and adjust the saturation.



The Setup Menu System

Advanced Features

2.5 SPEAKER SETUP

The speaker setup options are illustrated below:


2.5.1 DOWNMIX

- A) LT/RT Choose this setting when you are connected to a 2 Channel Analog Audio Input.
- B) STEREO Choose this setting when the DVD player is connected to a TV or therefore modulator.
- C) VSS Choose this setting to listen to the soundtrack effects, recorded on disc formatted in 5.1 Channel Surround Sound.
- D) 5.1CH Choose this setting when the DVD player is connected to a 5.1Channel Surround Sound System.




2.5.2 SUBWOOFER

There are two settings in this option: OFF/ON. When ON is chosen, the player will automatically detect and play the subwoofer. When OFF is chosen the subwoofer will not play.




2.5.4 CENTER

You can adjust the center and the rear delay by using the Up and Down buttons to move the scroll the scroll bar.



2.5.5 REAR DELAY

You can adjust the Center and the Rear delay by using the Up and Down buttons to move the scroll bar.




The Setup Menu System

Advanced Features

2.5.3 BASS MODE

There are Three settings in this option: ALL LG SPK, ALL SM SPK, MIXED SPK




2.6 DIGITAL SETUP

The DIGITAL SETUP options are illustrated below:

2.6.1 OP MODE

LINE OUT: Choose this setting to line out the input signal. It will be more suitable for playing in the night time, for the output volume is low.

RF REMOD: It will be more suitable to choose this setting for playing in the day time, for the output volume is high.




The Setup Menu System

Advanced Features


2.6.2 DYNAMIC RANGE:

When LINE OUT is selected, choose this setting to adjust the line out ratio for different effects.



2.6.3 DUAL MONO (LEFT + RIGHT)

Choose to setup the L and R mono output mode. There are four modes in this option: STEREO, MONO L, MONO R, and MIX MONO.



REFERENCE:

1. To protect your DVD player, the interval between turning the unit on and off, via the Main Power button, should be more than 30 seconds.
2. If the unit will not be used for an extended period of time, please disconnect the power plug from the outlet.
3. The player should only be operated with the correct power supply that corresponds to the marking label. The incorrect power supply could damage the unit.
4. The player may not be compatible with some encrypted discs.
5. If the player stops during playback, eject the disc and power off the unit. Wait 10 minutes and power the unit back on.


The Setup Menu System

Advanced Features

DISPLAY



During playback, press DISPLAY to show the current time counter position.




Press DISPLAY to show the Audio and Subtitle message menu.



TIME




During playback, press TIME to show the TIME SEARCH menu.



The Setup Menu System

Advanced Features

Press **Time** again to show the remain play time.



GOTO



During playback, press **GOTO** to show the current time counter position.



Use the number keys to input the desired Time, Title or Chapter, then press **ENTER** to confirm.

STANDBY



- During playback, press **STANDBY** to stop the player and return to standby mode.
- While the player is in standby, press **STANDBY** or any key on the front panel to resume normal.

OPEN/ CLOSE



- To open the disc tray, press **OPEN/CLOSE**.
- To close the disc tray, press **OPEN/CLOSE** again.

Remote Control Operation

Advanced Features

0-10+ keys



- These keys are used to input the time, as well as title, chapter and track numbers.
- When a numeric item is displayed on the screen, press the 0-10+ keys to select the desired entry, and press SELECT to confirm.

A-B



- During playback, press A-B to select point A.
- Press it again to select point B. The player will repeat the section from A to B automatically.
- Press A-B third time to cancel A-B repeat and clear points A and B.

*Note: 1. During CD playback, points A and B must be within the same track.
During DVD playback, points A and B can be selected from different chapters.
2. This function is subject to the disc.*

SLOW



- During DVD or CD playback press corel hold slow. The player will review the disc at 1/2, 1/3, 1/4, 1/5, 1/6, 1/7 times normal speed at follows. Slow → SF 1/2 → 1/3 → 1/4 → 1/5 → 1/6 → 1/7 → play

RETURN



- During DVD or CD playback press RETURN. The player will return to the menu.

FWD



- During DVD or CD playback, press and hold FWD to scan forward. The player will review the disc at 2, 4, 8 and 20 times normal speed as follows:

→→→ X2 →→→ X4 →→→ X8 →→→ X20

Press PLAY to resume normal playback.

REV



- During DVD or CD playback, press and hold REV to scan in reverse. The player will review the disc at 2, 4, 8 and 16 times normal speed as follows:

←←← X2 ←←← X4 ←←← X8 ←←← X20

Press PLAY to resume normal playback.

PREV



- Press PREV to skip to previous chapter or track.

Remote Control Operation

Advanced Features

NEXT



- Press NEXT to skip to the next chapter or track.

STOP



- Press STOP once during playback to stop and hold playback.
- Press PLAY to resume playback from the point you pressed STOP.
- Press STOP twice to stop playback completely.

PLAY



- Press PLAY from stop mode to start play.

PAUSE



- Press PAUSE during playback to pause playback.
- Press PLAY to resume normal playback.

MENU



- During DVD, playback, press MENU to return to the program menu.
- Note: This function is subject to the disc.

TITLE



- During DVD, playback, press TITLE to display the DVD title menu or play the first title.

Note: This function is subject to the disc.

REPEAT



- Select to press REPEAT to select Repeat Title, Repeat chapter, Repeat off During DVD playback.
- Press REPEAT to select Repeat Single, Repeat all and Repeat off (CD or Other).

Remote Control Operation

Advanced Features

VOL- VOL+



- Press Volume < VOL+> button to increase Volume.
- Press < VOL-> button to reduce Volume till to no volume output.

MUTE




- Press MUTE to mute the Audio output.
- Press MUTE again to resume normal Audio output.

ZOOM



- During DVD playback, press ZOOM to magnify the image as follows:



ANGLE



During DVD playback

- Press ANGLE to view scenes from different camera angles.
- Press ANGLE repeatedly to change from one camera angle to another.

Note: This function is disc specific.

LANGUAGE



During DVD playback

- Press LANGUAGE repeatedly to select from up to 8 Audio language/formats.

Note: This function is disc specific.

SUBTITLE



During DVD playback

- Press SUBTITLE repeatedly to select from up to 32 subtitle languages.

Note: This function is disc specific (languages will vary)..

P/N



- During playback press P/N to select PAL, AUTO, NTSL.

DIGEST




- During playback press DIGEST to display picture (This function is subject to the VCD.)

Remote Control Operation

Advanced Features

PROG



While [PROGRAM] is on, press ENTER to display the [Program] submenu:

CD Others

Program Input			
1__	4__	7__	10__
2__	5__	8__	11__
3__	6__	9__	12__

Play Program ClearAll

Input the track numbers in the order you would like them to play. When finished, select [Play Program] and then press ENTER to play the tracks in the new programmed order. Select [Clear All] and press ENTER to clear all the numbers you have input.


DVD

Program Input		Title/ chapter	
1__	4__	7__	10__
2__	5__	8__	11__
3__	6__	9__	12__

Play Program ClearAll

Input the title number and the chapter number in the desired order. Then select [Play Program] and press ENTER to play the chapters in the order you have set.. Select [Clear All] and press ENTER to clear all the numbers you have input.

L/R





- When a DVD is played, the active dubbing language will be shown. When a SVCD or VCD is played the left track, right track or stereo will be displayed accordingly.
- When a bilingual story VCD is played, you may press the button to select the language desired.

MPEG4/MP3 PLAYBACK

Advanced Features

When a MPEG4 and a Mp3 disc is loaded, the screen will display as follows:



Press $\triangleleft$ $\triangleright$ to select the file when the cursor appears in the file window.

Press $\triangleright$ to play the current file select by the cursor.

Press $\triangleleft$ $\triangleright$ to switch between the directory window and the file window.

Note: The player will not function correctly under the following condition:

1. The disc is badly scratched, damaged or dirty.
2. The disc is not finalized.
3. The recording format is not supported by the player.

USB interface

This unit have a USB jack,when no disc in the player, you can insert a USB DISC or a Mp3 Player with USB Interface to play the Mp3 music or and JPEG files. All the function is the same to play a disc.

The introduction of KODAK Picture CD

A Kodak Picture CD has the size and shape of a regular CD. You can order a KODAK Picture CD simply by checking the box on the photo finishing envelope when you drop off a roll of film (35 mm or Advanced Photo System (APS) color print film) at the time of processing in Kodak Express store displaying "Kodak Picture CD" sign. When your order is returned, you receive your prints, negatives, and your full roll of pictures safely stored on your KODAK Picture CD. Each KODAK Picture CD brings you the tools to enhance, share and manage your pictures on your computer. You also can record the JPEG picture into CD-R or CD-RW with the CD-Rewriter yourself.

- Note:** 1. The Max. Size of JPEG Picture can be supported: 3840X3840 pels
 2. JPEG stands for Joint Picture Experts Group. It is the first International Standard on Still Picture Compressing: ISO 10918-1, constituted by the Committee on Still Picture Compressing Standard of ISO. The pictures on KODAK Picture CD are stored in this format (JPEG). This player can decode the JPEG pictures in KODAK Picture CD and playback the pictures in different modes.

Now, you can playback Kodak Picture CDs on this player and view your wonderful pictures on your TV in the comfort of your living room.

When a Kodak Picture CD is inserted on a player an automatic slide show is launched. Each picture in the Kodak Picture CD will be displayed consecutively in a slide-show fashion and will be scaled to fit in the whole TV screen.

General function:


- You can set slideshow transition modes for any pictures.
- Press **PAUSE** to stop playing.
- Press **⏮** or **⏭** to see the previous or next picture.
- Press **PLAY** to continue slideshow transitions.
- Press **STOP** to return to root menu.

IMAGE ROTATION

- Press the **DIRECTION** button (⬆ ⬇ ⬇ ⬆) to rotation the image as you prefer.

Zoom Function:

This player provides both Zoom in/out and Zoom pan function. Press the **ZOOM** consecutively, the picture will zoom in/out in turn as followings:



- Note:** During the ZOOM function, slideshow transitions and image rotation are disabled.
 Q off: close zoom, press **PLAY** again to resume slideshow transition mode.

Troubleshooting

Other

If you have any questions, please consult the troubleshooting guide below.

NO PICTURE OR SOUND

- Ensure the power button is on.
- Ensure the power outlet is operational.
- Ensure the power cord is not damaged.
- Ensure the power plug is connected firmly to the outlet.

"BAD DISC" DISPLAYED

- Ensure the disc is not warped, damaged or deformed.
- Ensure the disc is not badly stained or damaged.
- Ensure the disc format is compatible with the player.
- Please check whether you have tried to play a software CD.
If so, please restart the player.

PICTURE BUT NO SOUND

- Ensure the audio jacks are securely connected.
- Ensure the audio connector is not damaged.
- Ensure the volume is turned up in VOL/CH setup.
- Ensure you have set the player's AUDIO settings correctly.
- Ensure you have entered the correct AV input for your TV.
- Ensure the audio is not set to mute.

REMOTE NOT WORKING

- Make sure the Main unit's POWER button is on.
- Ensure the remote batteries are working.
- Point the remote control directly at the player's IR sensor.
- Remove any obstacles between the remote and the IR sensor.

SOUND BUT NO PICTURE

- Ensure the video jacks are securely connected.
- Ensure you have entered the correct AV input for your TV.
- Ensure the video connector is not damaged.
- Ensure you have set the player's VIDEO settings correctly.

UNIT NOT WORKING

- Turn off the power, and then turn it on again.

POOR PICTURE OR SOUND

- Ensure you have set the player's AUDIO settings correctly.
- Ensure the disc is not scratched or stained.
- Ensure the AV connector or the output terminal is not damaged.

"NO DISC" DISPLAYED

- Ensure you have put the disc on the tray.
- Ensure the disc is not upside down.
- Ensure the disc is not distorted, stained or scratched.


Remote Control Preparation

Other

Insert batteries


1

1. Open the cover.



2


2. Insert batteries.



Make sure to match the "+" and "-" of the batteries with the marks inside the battery compartment.

3

3. Close the cover.



Notes:

Improper use of batteries may cause battery leakage and corrosion. To operate the remote control correctly, follow the instructions below:

Do not insert the batteries in the wrong direction.

Do not charge, heat, open, or short-circuit the batteries.

Do not throw batteries into a fire.

Do not leave dead batteries in the Remote Control.

Do not use different types of batteries together, or mix old and new batteries.

If you do not use the remote control for a long period of time, remove the batteries to avoid possible damage from battery corrosion.


If the remote control does not function correctly or the operating range becomes reduced, replace all batteries with new ones.

If battery leakage occurs, clean the battery compartment, then insert new ones.

Using the remote control

Point the remote control at the remote sensor.

(The pictures below are for reference only.)



Remarks: Do not expose the remote sensor of the DVD Player to a strong light source, such as direct sunlight.

Notes:

- Point the remote control directly at the player's remote sensor.
- Do not leave the remote control in an extremely hot or humid place.
- Do not spill water or put anything wet on the remote control.
- Battery life is ~1 year under normal conditions.

Specifications

Other

Power requirements: AC 100-240 Volt, 50/60Hz

Power consumption: 15W

Video standard: NTSC/PAL/AUTO

Unit Weight: 2.065kg

Video out

Video out: 1.0V(p-p)/75 Ω , sync, negative polarity, RCA pin jack x 1

S-video output connector(separate Y、C signal output connector):

Y output: 1.0V(p-p)/75 Ω , sync, negative polarity

C output: 0.286V(p-p)/75 Ω

Audio out

5.1 channel out: RCA pin jackx6

Coaxial out: 0.5V(p-p)75 Ω , RCA pin Jack x1

Frequency response: 20Hz to 20kHz

S/N ratio:>90dB

Total harmonic distortion: <0.0025%

[Accessories]

Video/ Audio cable x 1

Remote Control x 1

User' s Manual x 1

Specifications are subject to change without notice.

Weight and dimensions are approximate.